

ORION ELECTRONICS

=====

OPERATION MANUAL MODEL NO.: BPD-6A-S

Sr. No. _____

Batch No. _____

=====

4041, Bhandup Industrial Estate,
L.B.S. Marg, Bhandup (W),
MUMBAI : 400 078

Tel : 022-2564 1671, 022-2569 3478
Email : orionele@vsnl.com
URL : www.orionele.com

STEPPER MOTOR DRIVE : BPD-6A-S



INDEX**INDEX****INDEX**

- **GENERAL INTRODUCTION**
- **ABOUT THE SUPPLIED SYSTEM**
 - SPECIFICATIONS
 - CONTROLS AND INDICATORS
 - SETTINGS OF THE DRIVE
- **INSTALLATION**
- **CONNECTION DETAILS**
- **FAULT FINDING**
- **A FEW POINTS WORTH NOTING**

ABOUT THE SUPPLIED SYSTEM

The system is a stepper motor drive, controlled by signals from your external controller. The transformers are housed in a separate enclosure of same size. There are three signal inputs to drive from controller. They are-

- Start
- Direction
- Clock

The acceleration and retardation, of course has to be taken care by the controller. The motor starts when current flows through the input LED of the optocoupler. The default setting is ENABLE, which means that the motor will be energized and will have holding torque, when stopped.

SPECIFICATIONS

Control supply	230 vac, 1 ph, 50 Hz (195 to 255 vac)
Drive type	Bipolar, Half Step
Drive current capacity	6.5 Amp max
Controls	NPN 24 V signals (external)
Protection	Fuse for mains supply 3 Amp (5 X 20), glass Fuse for motor supply 4 Amp. (5 X 20), glass
Size : Drive box	290 (L) X 150 (W) X 115 (H) 40 mm Cooling fan on top.
Transformer box	170 (L) X 130 (W) X 115 (H)

SETTINGS OF THE DRIVE

Current setting

The current has to be adjusted to the appropriate value for the chosen motor. Connect a digital voltmeter to the test points provided on the front plate of the drive box. Ensure that the drive is in enabled, by activating the start signal. This is extremely important; because after the start signal de-activates, the current setting is automatically reduced to half, and if current setting is carried out during this state, the actual current in start state will be double. The formula is-

$I = V\text{-ref} \div R\text{-sns}$, where

I = per phase current of motor.

V-ref = Voltage at test points on PCB

R-sns = 0.11, (the value of sense resistor)

For example, for a current setting of 4 Amps, the Vref should be set at 0.4 to 0.44 V. The clockwise motion of preset will decrease the setting.

The value is adjusted to 6 Amp / ph, by default. (if not specified in your P.O.)

Direction Setting

It is seen that the forward and reverse motion conventions differ from place to place and also due to gearing or coupling of the mechanism etc. A switch is provided on the drive fascia, by which you can change or set the direction of motion, when your external signal is active.

Holding Torque Setting

In case of stepper motor, in stopped state, the drive setting can be chosen, so that, the system provides holding torque. Generally, the drive should be set to possess holding torque. We refer to this as ENABLE mode. On the mother board, you will find a 4 pin header adjacent to the edge connector. If a shorting cap is inserted on the two pins near to the edge of the pcb, the ENA-DIS will be controlled by the toggle switch. If the shorting cap is inserted on the other two pins, the drive will automatically get disabled after set time. This timing is 10 sec from the last start signal received.

CONNECTION DETAILS

To Transformers

4 Pin connector for motor supply

Pin no 1 & 2	}	90 VAC
Pin no 3 & 4		

5 Pin connector for control supply

Pin no 1	}	16 VAC
Pin no 2		

Pin no 3 No connection

Pin no 4	}	12 VAC
Pin no 5		

2 Pin connector for service supply

Pin no 1	}	18 VAC
Pin no 2		

To Motor

4 Pin connector to motor

Pin no 1 A1	}	One winding
Pin no 2 A2		

Pin no 3 B1	}	Other winding
Pin no 4 B2		

9 pin D type connector for signals

Pin no 1 Clock +

Pin no 2 Direction +

Pin no 3 Start +

Pin no 4 No connection

Pin no 5 Clock -


Pin no 6 Viso+ (approx 24 V)

Pin no 7 Direction -

Pin no 8 Start -

Pin no 9 0 V (Viso ground)

Drive pcb as seen from component side




H1 INSERTED = FULL STEP
 H1 OPEN = HALF STEP

The standard header settings are shown. Jp 1 for direction Jp2 for start and Jp3 for Enable / Disable

For checking or setting current, connect multimeter on voltage range 2 V, at points 1 and 3 on TPC test points, confirm that start signal is active, Adjust SET potentiometer to get desired setting. Anticlockwise motion increases setting

Mother Board as seen from solder side




Voltages at various pins with respect to pin no 3 or 4 (gnd) when mains voltage is 230 VAC in normal condition

Pin no 1	0 V
Pin no 2	20 to 22 VDC
Pin no 5	135 VDC (V-motor + 15 VDC approx)
Pin no 6	120 to 125 VDC

9 Pin connector

Pin no 1	Clock+
Pin no 2	Direction +
Pin no 3	Start +
Pin no 4	No connection
Pin no 5	Clock -
Pin no 6	Viso +
Pin no 7	Direction -
Pin no 8	Start -
Pin no 9	Gnd iso

CONNECTIONS ON THE TRANSFORMER BOX



CONNECT MAINS POWER TO TERMINALS MARKED 'L', 'N', 'E'.
 CHECK AC VOLTAGE AT TERMINALS 1 AND 2....16 V
 CHECK AC VOLTAGE AT TERMINALS 3 AND 4....18 V
 CHECK AC VOLTAGE AT TERMINALS 5 AND 6....12 V
 CHECK AC VOLTAGE AT TERMINALS 7 AND 9....95 V

OTHER ORION PRODUCTS

STEPPER MOTOR DRIVES (BIPOLAR)-

BPD-3A3-C = 230 VAC CONTROL SUPPLY, EXTERNAL SIGNALS & TEST MODE

BPD-3A3-E = 230 VAC CONTROL SUPPLY, ONLY EXTERNAL SIGNALS

BPD-3A3-S = 24 VDC CONTROL SUPPLY OR 36 VDC & 12 VC DUAL SUPPLY

BPD-6A+ = ANALOG INPUT FOR SPEED, START, DIRECTION & SLOW SIGNALS FROM
EXTERNAL CONTROLLER

BPD-9A-S = 230 VAC CONTROL SUPPLY, MOTOR CURRENTS UP TO 10 AMPS

MSD-3A-8 = 230 VAC CONTROL SUPPLY, MOTOR CURRENTS UP TO 3 AMPS
800 OR 1600 STEPS / REV, TEST MODE

MSD-3A-64 = 230 VAC CONTROL SUPPLY, MOTOR CURRENTS UP TO 3 AMPS
3200 OR 6400 OR 12800 STEPS / REV, TEST MODE

CONTROLLERS-

PLASTIC BAG MAKING MACHINE

CUT TO LENGTH SYSTEMS

FOIL STAMPING

2 & 3 AXIS ENGRAVING / MILLING MACHINES

TUBE FILLING & SEALING MACHINES

VISIT www.orionele.com to find out more....

IT WILL BE ORION ELECTRONICS' SOLE DISCRETION TO MAKE NECESSARY FUNCTIONAL CHANGES OR MECHANICAL DIMENSIONS, TO SUIT THE CUSTOMER'S REQUIREMENT, OR THE APPLICATION. ORION ELECTRONICS IS NOT BOUND TO ISSUE AN ADVANCE NOTICE, IN THIS REGARD.

THE OPERATION MANUAL IS A GENERAL GUIDELINE FOR THE BENEFIT OF CUSTOMER, INSTALLING THEIR UNIT. THERE MAY BE SOME DEVIATION IN THE ACTUAL UNIT AND THE DETAILS STATED IN THE MANUAL. ORION ASSUMES NO RESPONSIBILITY FOR THESE DEVIATIONS. HOWEVER, ORION SUPPORT STAFF WILL BE AS NEAR AS YOUR TELEPHONE, FOR ANY GUIDENCE NECESSARY.